


ADJUSTING INSTRUCTIONS FOR H-LEG

HEIGHT ADJUSTMENT:

1. REMOVE THE (4) 1/4"-20 X 3/8" BOLTS.
2. SLIDE LOWER HALF OF CPU HOLDER ASSEMBLY UP OR DOWN TO DESIRED HEIGHT. ALIGN NEAREST HOLES AND SECURELY TIGHTEN BOLT DO NOT OVER TIGHTEN.



1800 SITE SERVICES.COM / EMAIL: INFO@SITE.SERVICES.COM / PHONE: 1-800-854-1411
1602 LRPARK DRIVE - FARMINGTON, MISSOURI 63643 - FAX: (573) 756-2384
Part # IN003052 e - Revision Date: 015/05